

V7.10 Fallback (EMERGENCY USE ONLY)

**BE SURE BATTERIES ARE FULLY CHARGED OR
IN GOOD CONDITION BEFORE PROCEEDING
SERIOUS DAMAGE MAY OCCUR IF TRUCK FAILS
TO FLASH...**

Click google drive link below.

<https://drive.google.com/open?id=0B2oni3x7TmJFRkN2RXE2MjVtcm8>

Click download on the upper right corner (arrow) and then click the blue "download anyway" button.

Let the "v710_Fallback.zip" download to your PC (237 MB File).

Once zip file is downloaded to your PC, open the v710_Fallback.zip.

Move the containing "tuning files" folder to somewhere safe/easily accessible (such as your desktop).

You will be returning to it later.

NOW GO OUT TO TRUCK

1. Return truck to stock file (Do not start once procedure is completed).
2. Shut down, device and pull take out SD card of the device.

NOW GO BACK TO PC

3. Insert SD card into PC and open it up.
4. Locate and rename the current "tuning files" folder "tuning files_v1001".
5. Remove the current "tuning files_v1001" folder located in your SD card and move, it to somewhere safe such as (a folder on your desktop).
6. Move the new "tuning files" folder, that was moved to the desktop earlier (in the instructions) to your SD card.

7. Look over SD card and make sure, that the files were placed correctly.

**NOW GO OUT TO TRUCK AND LOAD A
TUNE.**