

**W/O KEYLESS ENTRY**

**SEE POWER DISTRIBUTION PAGE 13-19**

**HOT AT ALL TIMES**

**FUSE PANEL PAGE 13-15**

**RIGHT FRONT COURTESY LAMP SWITCH**

**MAIN LIGHT SWITCH PAGE 13-19 SEE PAGE 14-1 FOR SWITCH TESTING**

**LEFT FRONT COURTESY LAMP SWITCH**

**CREW CAB WITH XLT**

**WARNING CHIME PAGE 66-1**

**LEFT FRONT DOOR COURTESY LAMP**

**LEFT REAR DOOR COURTESY LAMP**

**SEE GROUNDS PAGES 10-13, 10-14, 10-15**

**COMPONENTS AND WIRING:**

- Glove Compartment Lamp:** Connected to C292, LG/V, 54, 12V, C292, BK, 57.
- Right Front Courtesy Lamp Switch:** Connected to C262, LG/V, 54, 12V, C262, BK/LB, 53, C228M, C228F, BK/LB, 53, C606, 12V (SWITCH CLOSED), BK, 57, C228F, C228M, BK, 57, S203, BK, 57.
- Main Light Switch:** Connected to S214, LG/V, 54, C200M, C200F, LG/V, 54, S251, LG/V, 54, C263, 12V, C263, LG/V, 54, C263, 12V (SWITCH CLOSED), 159, R/P/K, 53, BK/LB, 53, C303M, C303F, BK/LB, 53, C214M, C214F, BK/LB, 53, C504, 12V (SWITCH CLOSED), BK, 57, C504, BK, 57, S500, BK, 57.
- Left Front Courtesy Lamp Switch:** Connected to C263, LG/V, 54, C263, 12V, C263, LG/V, 54, C263, 12V (SWITCH CLOSED), 159, R/P/K, 53, BK/LB, 53, C303M, C303F, BK/LB, 53, C214M, C214F, BK/LB, 53, C504, 12V (SWITCH CLOSED), BK, 57, C504, BK, 57, S500, BK, 57.
- Left Front Door Courtesy Lamp:** Connected to C504, BK/LB, 53, C504, 12V (SWITCH CLOSED), BK, 57, C504, BK, 57, S500, BK, 57.
- Left Rear Door Courtesy Lamp:** Connected to C700, BK/LB, 53, C700, 12V (SWITCH CLOSED), BK, 57, C700, BK, 57, S500, BK, 57.
- Warning Chime:** Connected to 159, R/P/K, 53, BK/LB, 53, C303M, C303F, BK/LB, 53, C214M, C214F, BK/LB, 53, C504, 12V (SWITCH CLOSED), BK, 57, C504, BK, 57, S500, BK, 57.